

GANN BL TF IR 2

QUICK GUIDE



1. Turn the centre power button on located in the centre of the unit below the screen.
2. Press the centre M button to start the measurement process. During the measurement process the % symbol will blink while the value adapts to surrounding conditions. After releasing the M button, the % symbol is displayed, and the HOLD symbol also appears. The metre is now ready.
3. Press the M button again to start a new measurement.
4. If no TF stick plugged in, it is possible to measure the IR surface temperature. Plug in TF stick at the top of the device to use the other functions.
5. Click the down button to scroll through the 5 different setting modes, once landing on the measurement mode desired, select the M button to confirm mode. (Information and explanations of the individual measure modes can be found in the manual)
6. Hold the M button down for longer than 2 seconds to change the laser pointer from ON/OFF and hit the M button again momentarily to select.
7. Select the M button and scroll through settings to bring up MAX or MIN values in which only relative humidity is displayed.
8. Make use of the saved measurements where the last 5 measurements can be saved and recorded into relevant program. Use the down button to scroll through saved measurements where r1 – r5 is listed on the bottom centre of the screen. By using the UP and DOWN arrows and the M button to select, saved measurements can be cycled through.
9. If no button is pressed within approx. 40 seconds, the device switches off automatically. The current values are retained and are displayed again after the unit is switched back on.

