GANN CH 17 Software Upgrade for Derived Wood Products

- Download GANN Dialog Pro from the link below: <u>https://www.gann.de/en/info/downloads#software-downloads</u>
- Connect the CH 17 to your computer
- Select "data transfer" (or similar) on the screen of the CH 17
- Open GANN Dialog Pro
- The software should recognise the meter and "find" the software that is available for your devices serial no.
- Follow the instructions on the PC screen (your confirmation for the download may be required)
- It might be necessary to download some drivers. In the menu of the dialog pro software, there is a symbol of a spanner. When you click on that symbol, there should be an item called "Install Hydromette CH 17 drivers". Click on this, and after the installation, try again.



CREATING HEALTHY INDOOR ENVIRONMENTS

"On The Job" Industry Experience Since 1995

