



Dual Wand Pack – How To Install



1

Black cuff inserts into the Vacuum tank.



Original black vacuum hose

2

50mm cuff – internal cuff – 50mm cuff.



For maximum suction with the dual wand, cut the original black vacuum hose 1 meter in length from the black cuff inserted into the vacuum tank.

Keep the remaining original black vacuum hose, you will use this with the included cuffs below. When using the original single wand and floor tool.

3

To connect the dual wand, connect the original black vacuum hose to the included Y Piece with the included 50mm cuff.



4

Connect the included 2 x 38mm cuffs to the included Y Piece. Cut the 15mtr vacuum hose in half, connect the 2 x lengths of vacuum hose to the 2 x 38mm cuffs. Dual wand is now ready for use.

CREATING HEALTHY INDOOR ENVIRONMENTS

"On The Job" Industry Experience Since 1995

