

T210

QUICK GUIDE

1. Turn on power right hand side.
2. Using the left hand arrow (west) you can scroll between:
Actual reading,
Minimum reading,
Maximum reading,
Average reading
and hold to take screen readings (on the hold button to change to take a new screen reading press the tick button).
3. The Down arrow (south) rotates between:
Temperature and Relative humidity,
Dew Point Temperature and Temperature,
Dew Point Fahrenheit and Temperature Fahrenheit,
Grams per meter Cubed and Temperature,
Grams per Kilo and Temperature,
Grains per pound and Temperature Fahrenheit.

